

Module	CORBA Interface	Operation/Feature	RT CORBA Para #	SCA Full CORBA Profile	SCA Lightweight CORBA Profile	SCA Ultra-Lightweight CORBA Profile
RTCORBA	PriorityModelPolicy	SERVER_DECLARED	RTCORBA.idl	MAN	NRQ	NRQ
		create_threadpool	2.10	MAN	NRQ	NRQ
	Thread Pools					
		create_threadpool_with_lanes	2.10	MAN	NRQ	NRQ
RTPortableServer	POA	activate_object_with_priority	2.7.5	MAN	NRQ	NRQ